

# GLOSSARY OF TERMS

- AdjustaFlex** . . . . . Flexsteel patent-pending arm height adjust system on treatment recliner.
- Antimicrobial** . . . . . Finish added to wood and fabrics to prevent septic infection.
- Cal 133** . . . . . Flammability code required by state of California for fabric/foam.
- ComfortFlex** . . . . . Flexsteel chair line featuring patent-pending DualFlex spring seat suspension and SpringFlex back system.
- Dowels** . . . . . Small wood pegs that insert into round joints and strengthen corners of wood frame furniture.
- DualFlex** . . . . . Patent-pending seat support system featuring durable 2-inch wide “W” high-strength steel bands and helical coils.
- FlexBack** . . . . . Chair term referring to a back that rocks as you press back on it; seat does not move.
- FlexLock** . . . . . Part of the patent-pending Flexsteel SpringFlex seat system that locks the back in an upright position keeping it from rocking.
- Fold-N-Tumble** . . . . . Exclusive Flexsteel sleeper chair and sleeper sofa line.
- Foley Bag** . . . . . Blood bag holder attachment used on treatment recliner.
- Guest Chair** . . . . . Low-back, all-wood, or upholstered chair used by guests of acute care patients. Found in patient room or exam rooms.
- HPL** . . . . . High-pressure laminate wood top found on bedside cabinets.
- Krypton** . . . . . Trademarked finish applied to fabrics to prevent wear and soil.
- Melamine** . . . . . Man-made laminate resin used on bedside cabinet tops.
- Mortise & Tenon** . . . . . A simple and strong joint made by interlocking an elongated wood slat into a horizontal slot.
- Patient Chair** . . . . . Chair used by patient after surgery or procedure. Found in patient room.
- SpringFlex** . . . . . Exclusive Flexsteel patent-pending rocking mechanism used on ComfortFlex chair line featuring spring loaded durable flex and lock option.
- Tente** . . . . . Four-inch casters used on treatment recliner. Option for locking or non-locking.
- Trendelenburg** . . . . . Position adjustment on treatment recliner that moves patient’s head below knees.
- Veneer** . . . . . All-wood facia applied to tops and sides of bedside cabinets.
- Ziggers** . . . . . S-shaped steel wire springs used in seat support systems on furniture.