



FINISH PROCESS

Flexsteel is committed to quality, that's why inspection follows each of the 12 steps in our five-hour finish process.

This ensures not only the best possible finish for your furniture – but also longevity, delivering on the durability needed for today's healthcare environments.

All surfaces are hand-sanded with 220 grit sponge pads prior to glaze application. Giving added depth to the finish color.

At Flexsteel, all our finishes are solvent free, water based and coated with our rugged FlexGuard II antimicrobial topcoat. Boasting an 85 Sheen Kem Aqua Microband™ Antimicrobial Lacquer, Flexsteel delivers an industry-leading 2.0 mil. of protection, compared to the required 1.6 mil. of other companies.

We understand the demands of the healthcare industry, that's why we take our finish process so seriously.

FlexGuard II

- Pre-catalyzed lacquer topcoat that exceeds the furniture industry standards for finishes.
- Highly durable finish is tested to perform in the harshest conditions using ANSI/KCMA standards and 24-hour exposure to the toughest challenges:
 - Vinegar
 - Lemon, orange and grape juices
 - Water glasses
 - Soda cans
 - Ketchup
 - Mustard
 - 115-degree coffee
 - Olive oil
 - Wet towels
 - 100-proof alcohol
 - Various cleaning products
- Topcoat that protects our wood finishes from water and other materials.
- Effective alternative to high-pressure laminates.
- This is a waterborne product which is free of Volatile Organic Compound (VOC) and Hazardous Air Pollutants (HAP).

To learn more about Flexsteel Acute Healthcare
visit www.FlexsteelAcuteHealthcare.com
or contact Flexsteel Customer Care
385 Bell Street, Dubuque, Iowa 52001
Phone 502.426.4351 • Fax 800.444.5481

